










**MAINTENANCE BOX ~ WASTE INK PAD ~ PICK UP ROLLER**

Sr	Product Description / Code	MB Box with chip Dealer Rate	Only Chip Dealer Rate	Printer Comaptibility	Image
1	MB - Maintenance Box <b>MC-G01</b>	490.00	—	Canon MAXIFY GX5070/ GX5570/ GX6070/ GX6570/ GX7070 Printers	
2	MB - Maintenance Box <b>MC-G02</b>	442.00	<b>CP801</b> 110	Canon PIXMA G1020/ G2020/ G2021/ G2060/ G3021/ G570/ G670 Printers	
3	MB - Maintenance Box <b>MC-G04</b>	484.00	<b>CP805</b> 120	Canon PIXMA G1730/ G1737/ G2730/ G2770/ G3730/ G3770/ G4770 Printers	
4	MB - Maintenance Box <b>C9346/L15160</b>	360.00	<b>CP647</b> 104	Epson L15150 / L15160	
5	MB - Maintenance Box <b>C9344 / L3560</b>	382.00	—	Epson L3560 / L3550	
6	MB - Maintenance Box <b>T04D1/ L6170/ M2140</b>	302.00	<b>CP644</b> 104	Epson L6170, L6190, L14150, M1140, M1170, M1180, M2140, M2170, M3140, M3170, M3180	
7	MB - Maintenance Box <b>T6711/ L1455</b>	484.00	<b>CP643</b> 148	Epson L605, L655, L1455 Printers	
8	MB Maintenance Box- <b>S2100/SC13</b>	484.00	<b>CP648</b> 230	Epson SC-F530/ F570/ T3130/ T2100/ T5130 /SC-T3170 / T 5170/ T3180N Printers	
9	MB - Maintenance Box- <b>C9387/M 1050/2050</b>	390.00	<b>CP642</b> 140	Epson M1050 / M1058 / M2050	

Sr	Product Description / Code	Dealer Rate	Printer Comaptibility	Image
1	WP01 : Waste Ink Pad L 130 / L 210	55.00	Epson L110, L130, L210, L220, L310, L350, L355, L361, L360, L361, L365, L380, L385, L405, L455, L485 Printers	
2	WP11 : Waste Pad L 210 with container	72.00		
3	WP02 : Waste Pad L800 / L805	88.00	Epson L800 / L805	
4	WP03 : Waste Pad L 3110 / 3150	55.00	Epson L3110, L3115, L3116, L3150, 3110	
5	WP13 : Waste Pad L 3110 / 3150 with container	72.00		
6	WP04 : Waste Pad L8050 / L 18050	100.00	Epson L8050 / L 18050	

**formujet®**

Sr	Product Description / Code	Dealer Rate	Printer Comaptibility	Image
1	PUR 01 : Pickup Roller L130/ L210/ L360	104.00	EPSON L110/ L130, L210, L220, L300, L310, L350, L355, L360, L365, L455, L550, L555, L565	
2	PUR 02 : Pickup Roller L800 / L805	164.00	Epson L800/ L805/ L810/ L850	
3	PUR 03 : Pickup Roller L1300 / L1800	205.00	Epson L1800/ L1300/ L1390 / T1100 Printers	
4	PUR 04 : Pickup Roller L3110 / L3150	120.00	Epson L3110/ L3115/ L3116/ L3150/ L3156/ L5190 Printer	
5	PUR 05 : Pickup Roller L8050 / L18050	378.00	Epson L8050 / L18050	